

# **Data Sheet CODESYS HMI SL**

This product allows for the creation of operating interfaces with CODESYS visualization for an HMI device (PC or panel), with data from CODESYS V2 and CODESYS V3 controllers. The visualization is created with the CODESYS Development System (V3), the free IEC 61131-3 development system with a full-fledged visualization editor.

# **Product description**

CODESYS HMI SL is a software package that is installed on a remote computer to equip it with a graphical user interface (HMI). This new HMI support allows it to combine and visualize the data of one or more CODESYS V2 and CODESYS V3 controllers (data sources) on one remote HMI device.

# **Benefits**

- Integrated into the CODESYS Development System for development of the remote HMI
- Development in one project, either independently or with the PLC application
- Scalable projects by unlocking any number of available data points
- Simplified creation of the application by guided project configuration
- Automated display of all available data in the controller network
- Display of all functions and elements that are available with CODESYS Visualization, for example:
  - Alarm management
  - Trace and trend display
  - User management
  - Recipe management
  - · Visualization styles
- Download the visualization directly from the development environment to the HMI device

The following functions are available with the CODESYS HMI SL basic license: \* 10,000 data source points for linking CODESYS V2 and CODESYS V3 data \* 100 data server points for switching the data server product \* Symbolic or direct data linking \* Processing (read/write) of variable and recipe data \* Display of the contents of alarm tables and trend records \* Customization of the sampling rate of the visualization to the task cycle of the controller(s) \* Automatic management and generation of the required data types and data points \* Automatic conversion function for data server projects



Bild 1: Programming the CODESYS HMI within the CODESYS Development System

data sources of any CODESYS controller	Variables Type Mappings Communication General and Diagnosis					
	Application	<b>*</b>		***		Application
	PLC_PRG	5				PLC_PRG
	■ arr2	540				arr2
	🗷 arr	5				arr
	🕀 arrArrI	5				arrArrI
	arrArrStruct	5				arrArrStruct
		5				[0]
		5				[1]
	⊟ [0]	50				[0]
	a1	5			INT	a1
	b1	5			INT	b1
	c1	5			REAL	c1
	■ arrStruct	5				arrStruct
	🗈 inst1	50				inst1
		50				inst2
	■ inst3	5				inst3
	Inst4	5				inst4
	inst5	5				inst5
	a1	5			INT	a1

Bild 2: Working with data points and data sources

# Nominal

• Extension license for supporting an unlimited number of data points

# Functional

CODESYS WebVisu SL – a CODESYS Store product

### **General information**

#### Supplier:

CODESYS GmbH Memminger Strasse 151 87439 Kempten Germany

#### Support:

https://support.codesys.com

This product includes a CODESYS Support Ticket, i.e. 1 hour of support of CODESYS. More details can be found in the CODESYS Store product: CODESYS Support Ticket. Item: CODESYS HMI SL Item number: 230400009 Sales: CODESYS Store https://store.codesys.com

#### Included in delivery:

- Package for the CODESYS Development System including CODESYS Control, license agreement, online help and device description
- License Key

### System requirements and restrictions

Programming System	CODESYS Development System V3.5.10.0 or higher	
Runtime System	-	
Supported Platforms/ Devices	Executable under Embedded (32/64 Bit) / Windows 8 and 10	
	The versions maintained by Microsoft are supported.	
	Note: Use the project "Device Reader" to find out the supported	
	features of your device. "Device Reader" is available for free in the CODESYS Store.	
Additional Requirements	See license agreement. After installation, the user is responsible for implementing and checking the functionality of the combination of the software package and hardware according to device specifications.	
	Runtime with Datasource Manager	
Restrictions	-	
Licensing	Single device licensing	
	License activation optional on CODESYS Key or CODESYS Softcontainer (free of charge component of CODESYS Controls). Licensing via CODESYS Softcontainer is strictly linked to the selected hardware.	
	Note: Without a license the software runs in demo mode for two hours (manual restart is needed).	
Required Accessories	Optional: CODESYS Key	

Note: Not all CODESYS features are available in all territories. For more information on geographic restrictions, please contact sales@codesys.com.

Note: Technical specifications are subject to change. Errors and omissions excepted. The content of the current online version of this document applies.